

# VALVE PART BREAKDOWN

## 5800 ABRASIVE REGULATOR - MANUAL

<u>PART NUMBER</u>	<u>KEY</u>	<u>DESCRIPTION</u>
5800	(0)	COMPLETE VALVE
5701	(1)	Control Handle
5772	(2)	Retaining Pin
5703	(3)	Control Stem
5704	(4)	Packing Nut
5705	(5)	Packing
5707	(7)	Packing Retainer
5708	(8)	Valve Cover
5809	(9)	Hexhead Bolts (6) 3/8"-16 x 1-1/2", <i>each</i>
5706	(9)	Hex Nuts (6) 3/8-16, <i>each</i>
5710	(10)	Ball and Stem Nut
5791	(11)	Ball and Stem
5712	(12)	Diaphragm
5715	(15)	Valve Seat
5718	(16)	1" Clean Out Plug
5717	(17)	Valve Body

